



MISSOURI DEPARTMENT OF HEALTH
STATE PUBLIC HEALTH LABORATORY
DATAMASTER MAINTENANCE REPORT

BREATH ALCOHOL PROGRAM

Complete this report in duplicate at the time of the regular monthly preventive maintenance check and whenever instrument is repaired. Send copy to Department of Health; retain original in department file.

DATAMASTER SN <u>CHAFFEE POLICE DEPT 201203</u>	DHSS <u>06-05-09</u>
LOCATION OF INSTRUMENT (STREET AND CITY) <u>222 YOKUM CHAFFEE MO 63740</u>	DATE OF INSPECTION <u>06-05-09</u>
	TIME OF INSPECTION <u>14:09</u>

CHECKLIST: Place a check (✓) to the left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER <u>49°C</u>	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER
<input checked="" type="checkbox"/> INDICATOR LIGHTS	
<input checked="" type="checkbox"/> TIME AND DATE	
<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34 °C ± 0.2°C) <u>33.9 C</u>	
<input checked="" type="checkbox"/> CALIBRATION CHECK - Run three tests using a standard solution. All three tests must be within ± 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) (USE RECIRCULATION PUMP) <input checked="" type="checkbox"/> 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE <input type="checkbox"/> 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)	

TEST 1 <input checked="" type="checkbox"/> <u>.096</u>	TEST 2 <input checked="" type="checkbox"/> <u>.096</u>	TEST 3 <input checked="" type="checkbox"/> <u>.095</u>
--	--	--

☒ PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

☒ NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF BREATH TESTS IN EACH RANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS)

REFUSALS -0-	(0-.04) -0-	(.05-.09) -0-	(.10-.14) -0-	(.15-.19) -0-	(Over .19) -0-
--------------	-------------	---------------	---------------	---------------	----------------

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary)

CERTIFIED USING LOT 08002 REPCO MARKETING
SOLUTION 10 EXP OCT 13-2010

INSPECTING OFFICER	
SIGNATURE <u>[Signature]</u>	PRINT NAME <u>FRANK STOFFREGEN</u>
TYPE II PERMIT NUMBER/EXPIRATION DATE <u>820292 EXP 10-03-2010</u>	TELEPHONE NUMBER <u>573-264-2121</u>

CERTIFICATE OF ANALYSIS

Random samples of lot number 08002 of Alcohol Certified Solution for simulator were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain .1209 gms/dl wt. /vol. ethyl alcohol.

The alcohol and distilled water used in the solution were found to be free of any interfering substance.

When used in a calibrated simulator, operating at 34 c +/- .2 c, this solution will give an alcohol breath test instrument reading of .100 percent BAC +/- 2% or .002 BAC (whichever is greater).

The expiration date for this lot number is October 13, 2010 at 11:59PM.

This document is a true representation of the original Certificate of Analysis.



Cecil B. Garner, President
RepCo Marketing, Inc.

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
CHAFFEE POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201203
06-05-09

ARREST TIME: 13:00

SUBJECT NAME:

TEST

DOB: 12-12-80 SEX: M

STATE/D.L.: MO/12345

ARRESTING OFFICER:

STOFFREGEN/FRANK

OFFICER I.D.: 107

TESTING OFFICER:

STOFFREGEN/FRANK

OFFICER I.D.: 107

PERMIT NUMBER: 820290

EXPIRATION DATE: 10/03/10

MISCELLANEOUS DATA:

NFI TEST

--- BREATH ANALYSTS ---

BLANK TEST	.000	14:25
INTERNAL STANDARD	VERIFIED	14:26
RADIO INTERFERENCE		

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

BAC DATAMASTER SERIAL NUMBER 201203
06-05-09

TESTING OFFICER:

STOFFREGEN/FRANK

OFFICER I.D.: 107

PERMIT NUMBER: 820290

EXPIRATION DATE: 10/03/10

MISCELLANEOUS DATA:

--- SUPERVISOR NOTE ---

BLANK TEST	.000	14:15
INTERNAL STANDARD	VERIFIED	14:15
EXTERNAL STANDARD	.000	14:15
BLANK TEST	.000	14:16
EXTERNAL STANDARD	.000	14:16
BLANK TEST	.000	14:17
EXTERNAL STANDARD	.000	14:17
BLANK TEST	.000	14:18

N = 8

STDEV = .01

AVG. = .0056

Operator Signature

Operator Signature

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
CHAFFEE POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201208
60760-00
14700

--- BREATHING UNIT ---

COMPUTER	ONLY
PROGRAM	ONLY
HEATER	
SAMPLE CHAMBER	ONE
FLOW DETECTOR	ONLY
PUMP	
HIGH SPEED	ONLY
DETECTOR	ONLY
FILTER	ONLY
DOUBLE STANDARD	ONLY
CALIBRATION	ONLY

PRINTOUT TEST

10/00/00 10:00:00 10/00/00 10:00:00 10/00/00 10:00:00
10/00/00 10:00:00 10/00/00 10:00:00 10/00/00 10:00:00
10/00/00 10:00:00 10/00/00 10:00:00 10/00/00 10:00:00

Operator Signature

[Signature] 107

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
CHAFFEE POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201208
60760-00

ARREST LINE 13400

SUBJECT NAME

TEST

DATE 10/00/00 10:00:00

STATE/DEPT MO/0000

ARRESTING OFFICER

STREET ADDRESS/PHONE

OFFICER I.D.# 000

TESTING OFFICER

STREET ADDRESS/PHONE

OFFICER I.D.# 000

IDENTIFICATION NUMBER 000000

EXPIRATION DATE 10/00/00

MISCELLANEOUS DATA

BREATH TIME 10:00

--- BREATH ANALYSIS ---

BLANK TEST	ONLY	14700
INTERNAL STANDARD	VERIFIED	14700
SUBJECT SAMPLE	ONLY	14700
BLANK TEST	ONLY	14700

12 SEC
BREATH TEST

Operator Signature

[Signature]

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
TYPE II



FRANK STOFFREGEN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 10/03/08

Number 820292

Expires 10/03/2010

MO 580-0771 (7-88)

John J. Mathewson

Director of State Public Health Laboratory

Director, Department of Health

Lab. 4 (R7-88)