

MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY

COEATH ALCOHOL PROGRAM

DATAMASTER MAINTENANCE REPORT

Complete this report in duplicate at the time of the regula is repaired. Send copy to Department of Health; retain original	r monthly preventive mai Il in department file.	ntenance ch	eck, and whenever instrumen
201242 Foristell Police	Department);;;	DATE OF INSPECTION
LOCATION OF INSTRUMENT (STREET AND CITY)	1		TIME OF INSPECTION
CHECKLIST: Place a check (V) to the left of each item if for	16 43348 und to be satisfactory or i	if operating s	8:05 4m
in observed values where determined.) Unchecked items mus	t be corrected before usin	g instrument	
DIAGNOSTIC CHECK (PRINTOUT ATTACHED)			
COMPUTER	DETECTOR		
PROGRAM	1 FILTERS		
HEATERS SAMPLE CHAMBER 49_°C	🗹 QUARTZ STANDA	\RD	
FLOW DETECTOR	D CALIBRATION		
PUMP HIGH SPEED	M PRINTER		
☑ INDICATOR LIGHTS			
TIME AND DATE			
SIMULATOR TEMPERATURE (34 °C ± 0.2°C) 34°C	Buch Cinulator	2120	20ia/#NR5377
CALIBRATION CHECK -	OKIL SILINIANS	- XIUU J	AND DROOM
Run three tests using a standard solution. All three test spread of .005 or less. Check the box corresponding to	ats must be within \pm 5% the standard solution bei	of the stan	dard value and must have a RINTOUT ATTACHED) (USE
RECIRCULATION PUMP)		,	, ,
☑ 0.100% STANDARD - MUST READ BETWEEN 0.095% ☐ 0.040% STANDARD - MUST READ BETWEEN 0.038%	and 0.105% INCLUSIVE		
(ONLY ONE STANDARD IS TO BE USED PER MAINTEN	ANCE REPORT)		
TEST 1 699 % TEST 2 -	« /oo%	TEST 3	100%
PERFORM R.F.I. TEST (PRINTOUT ATTACHED)		•	* / *
NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF BREATH TESTS IN EACH RANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS)			
REFUSALS 3 (004) 0 (.0509)	1 1	1519)	(Over .19) 2
List any new parts and describe any alteration or modification	n that was made to restor	re the instru	ment to operate satisfactorily
and within established limits (use other side if necessary)		Gush	Lab Solution
installed New Eprom chip	· · · · · · · · · · · · · · · · · · ·	Fot 08:	/
		12.08.20	
		1011-0100	
00			
NSPECTING OFFICER	PRINI NAME (
4/5×10/mmm 70/	DG Jakns	SON	
9,08,2010	telephone number (636, 463, 2)		רבנ
		9 J Y	<i>aa</i> 1

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 08400 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1204 percent (w/vol) ethyl alcohol. The expiration date for this lot number is December 8, 2009 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

FACE THIS SIDE DOWN - THIS EDGE IN FI

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI FORISTELL POLICE DEPARTMENT

BAC BATAMASTER SERIAL NUMBER 201242 06/03/09

MRREST TIME: 07:00

SUBJECT MAME:

JOHNSON/1976

DOB: 06/03/09

SEX: M

STATE/B.L.: MO/1234567890

ARRESTIMG OFFICER:

JOHNSON/D/6

OFFICER I.D.: 781

TESTING OFFICER:

JOHNSON/D/G

OFFICER 1.D. POI

PERMIT HUMBER: 828262

EXPIRATION DATE: 09/06/10

MISCELLAMEDUS DATA:

REI TEST

--- BREATH AMALYSIS ---

BLANK TEST

. 866

981 15

IMTERNAL STANDARD RADIO INTERFERENCE

VERIFIED

98:48

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
FORISTELL POLICE BEPARTMENT

BAC DATAMASTER SERIAL MUMBER 201242 06/03/09 09:06

--- DIRBYOSTIC CHECK ---

COMPUTER:

OKHY

PROGRAM (04-07-2009):

OKAY

HEATERS

SAMPLE CHAMBER:

490

FLOW DETECTORS

OKRY

PHIME

HIGH SPEED:

OK#7

DETECTOR:

FILTERSA

OKAY

OKAY

GUARTZ STANDARD:

OKRY

CALIBRATION:

ÜKHY

PRINTER TEST

!"#\$%&^()*+,~./0123456789:;<=>?@ABCDEFG HIJKLMMOP@RSTUVWXYZ[\]^_^abcdefghijklmno pgrstuvwxyz(!)*~

OPERATOR SIGNATURE

Card Stock No. 60021

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901 OPERATOR SIGNATURE

Card Stock No. 60021

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOUR! FORISTELL POLICE DEPARTMENT -

BAC DATAMASTER SERIAL NUMBER 201242 06/03/09

TESTING OFFICER:
JOHNSON/IJ/G
OFFICER I.D.: 701
PERMIT NUMBER: 820262
EXPIRATION DATE: 09/08/10
MISCELLAMEOUS DATA:

- -- SUPERVISOR MODE ---

B比翰·W·TEST: " ** * * · · · · · ·	* * * * * * * * * * * * * * * * * * *	h-60°69
INTERNAL STAMDARU	VERIFIED	08:89
EXTERNAL STANDARD	.099	<u> </u>
BLANK TEST	. 808	B8419
EXTERNAL STANDARD	. 168	88:19
BLANK TEST	. 800	96211
EXTERNAL STAMDARD	. 100	90:18
BLANK TEST	. 969	08:12

'N = 3 | SIM. = .1 | AVG. = .0996

OPERATOR SIGNATURE

Card Stock No. 60021

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901

State of Missouri DEPARTMENT OF HEALTH



PERMIT TYPE II



DOUGLAS G. JOHNSON

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

09/08/08	Time C. Colont	
820262 Number 09/08/2010	Director of State Public Health Laboratory	
	Version and the second	
Expires	. Director, Department of Health	
MO 580-0771 (7-88)	lah 4/07-891	