



MISSOURI DEPARTMENT OF HEALTH
STATE PUBLIC HEALTH LABORATORY
DATAMASTER MAINTENANCE REPORT

BREATH ALCOHOL PROGRAM

JUN-9 2009

Complete this report in duplicate at the time of the regular monthly preventive maintenance check, and whenever instrument is repaired. Send copy to Department of Health; retain original in department file.

DATAMASTER SN 204067 INV# 127192	DATE OF INSPECTION 5-31-09
LOCATION OF INSTRUMENT (STREET AND CITY) DENT CO. JAIL	TIME OF INSPECTION 0939

CHECKLIST: Place a check (✓) to the left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER 49 °C	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER
<input checked="" type="checkbox"/> INDICATOR LIGHTS	
<input checked="" type="checkbox"/> TIME AND DATE	
<input checked="" type="checkbox"/> SIMULATOR TEMPERATURE (34 °C ± 0.2 °C) 34.00 °C	
<input checked="" type="checkbox"/> CALIBRATION CHECK - Run three tests using a standard solution. All three tests must be within ± 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) (USE RECIRCULATION PUMP) <input checked="" type="checkbox"/> 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE <input checked="" type="checkbox"/> 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)	

TEST 1 <input checked="" type="checkbox"/> .103%	TEST 2 <input checked="" type="checkbox"/> .104%	TEST 3 <input checked="" type="checkbox"/> .104%
---	---	---

<input checked="" type="checkbox"/> PERFORM R.F.I. TEST (PRINTOUT ATTACHED)											
<input checked="" type="checkbox"/> NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF BREATH TESTS IN EACH RANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS)											
REFUSALS	1	(0-.04)	0	(.05-.09)	1	(.10-.14)	6	(.15-.19)	0	(Over .19)	0

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary)

GUTH LABORATORIES SOLUTION LOT #08340, EXPIRES 10-15-09

OPERATING WITHIN MO.DOHSS SPECIFICATIONS

INSPECTING OFFICER	
SIGNATURE K.D. WILMONT	PRINT NAME K.D. WILMONT
TYPE II PERMIT NUMBER/EXPIRATION DATE 820094 03-10-10	TELEPHONE NUMBER (573) 368-2345



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-664-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **08340** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain **0.1211** percent (w/vol) ethyl alcohol. The expiration date for this lot number is **October 15, 2009** at 11:59 PM.

When used in a calibrated Simulator, operating at $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$, this solution will give a breath alcohol analysis instrument reading of **0.10** percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL
BAC DATAMASTER SERIAL NUMBER 204067
05/31/09

TESTING OFFICER:

WILMONT/K/D

OFFICER I.D.: 678

PERMIT NUMBER: 820094

EXPIRATION DATE: 03/10/10

MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLANK TEST	.000	09:42
INTERNAL STANDARD	VERIFIED	09:42
EXTERNAL STANDARD	.103	09:43
BLANK TEST	.000	09:44
EXTERNAL STANDARD	.104	09:44
BLANK TEST	.000	09:45
EXTERNAL STANDARD	.104	09:46
BLANK TEST	.000	09:46

N = 3

SIM. = .1

AVG. = .1036

Operator Signature

Printed on recycled paper with agri-based inks

CMSU 2

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL
BAC DATAMASTER SERIAL NUMBER 204067
05/31/09

ARREST TIME: 09:30

SUBJECT NAME:

DOE/JANE

DOB: 05/31/88 SEX: F

STATE/D.L.: MO/000000000

ARRESTING OFFICER:

WILMONT

OFFICER I.D.: 678

TESTING OFFICER:

SAME

OFFICER I.D.: 678

PERMIT NUMBER: 820094

EXPIRATION DATE: 03/10/10

MISCELLANEOUS DATA:

TEST ONLY

--- BREATH ANALYSIS ---

BLANK TEST	.000	10:16
INTERNAL STANDARD	VERIFIED	10:17
RADIO INTERFERENCE		

Operator Signature

Printed on recycled paper with agri-based inks

CMSU 2208-02

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL
BAC DATAMASTER SERIAL NUMBER 294067
05/31/09
09:39

----- DIAGNOSTIC CHECK -----

COMPUTER:	OKAY
PROGRAM:	OKAY
HEATERS	
SAMPLE CHAMBER:	49c
FLOW DETECTOR:	OKAY
PUMP	
HIGH SPEED:	OKAY
DETECTOR:	OKAY
FILTERS:	OKAY
QUARTZ STANDARD:	OKAY
CALIBRATION:	OKAY

PRINTER TEST

!"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHI
JKLMNOPQRSTUVWXYZ[\]^_`abdefghijklmno
pqrstuvwxyz{|}~

Operator Signature

K.D.W. [Signature]

Printed on recycled paper with agri-based inks

CMSU 2208-02

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
TYPE II



KYLE WILMONT

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 03/10/08

Number 820094

Expires 03/10/2010

MO 580-0771 (7-88)

Eric C. Polak
DIRECTOR OF MISSOURI DEPARTMENT OF HEALTH

Director, Department of Health

Lab. 4 (R7-88)