

MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY

DATAMASTER MAINTENANCE REPORT

RECEIVED DHSS Breath Alcohol Program By Carol Day at 10:21 am, Aug 27, 2009

| Complete this report in duplicate at the time of the regular is repaired. Send copy to Department of Health; retain original | monthly preventive maintenar in department file. | ice check, and whenever instrument | | | |
|--|---|---|--|--|--|
| DATAMASTER SN 204182 127 | 293 | DATE OF INSPECTION 08-18-09 | | | |
| LOCATION OF INSTRUMENT (STREET AND CITY) Vernon County Jail, Nevada | | TIME OF INSPECTION | | | |
| CHECKLIST: Place a check (<) to the left of each item if fou in observed values where determined.) Unchecked items must | nd to be satisfactory or if operabe corrected before using instr | ating within established limits. (Write | | | |
| DIAGNOSTIC CHECK (PRINTOUT ATTACHED) | | | | | |
| ☑ COMPUTER | ☑ DETECTOR | | | | |
| ☑ PROGRAM | ☑ FILTERS | | | | |
| ☑ HEATERS SAMPLE CHAMBER 50 °C | ☑ QUARTZ STANDARD | Q QUARTZ STANDARD | | | |
| ☑ FLOW DETECTOR | ☑ CALIBRATION | I | | | |
| ☑ PUMP HIGH SPEED | PRINTER | PRINTER | | | |
| ☑ INDICATOR LIGHTS | | | | | |
| ☑ TIME AND DATE | | | | | |
| SIMULATOR TEMPERATURE (34 °C ± 0.2°C) CALIBRATION CHECK - | | | | | |
| Run three tests using a standard solution. All three test spread of .005 or less. Check the box corresponding to RECIRCULATION PUMP) 0.100% STANDARD - MUST READ BETWEEN 0.095% On 0.040% STANDARD - MUST READ BETWEEN 0.038% ONLY ONE STANDARD IS TO BE USED PER MAINTENA | the standard solution being use and 0.105% INCLUSIVE and 0.042% INCLUSIVE | e standard value and must have a ed. (PRINTOUT ATTACHED) (USE | | | |
| TEST 1 - ,097 TEST 2 - | .098 TES | тз 🕶 .098 | | | |
| PERFORM R.F.I. TEST (PRINTOUT ATTACHED) | I | | | | |
| NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REFUSALS, SINCE REFUSAL | EPORT, AND NUMBER OF BRE | ATH TESTS IN EACH RANGE AS | | | |
| REFUSALS (004) 0 (.0509) 2 | (.1014) 🖒 (.1519 | Over .19) O | | | |
| List any new parts and describe any alteration or modification and within established limits (use other side if necessary) This instrument is operating within Department of Health S | | | | | |
| Guth Laboratories Solution Lot # 08340 RepCo Marketing Solution Lot# | Expiration Expiration | 10-15-09 | | | |
| INSPECTING OFFICER | PRINT NAME | | | | |
| TYPE II PERMIT NUMBER/EXPIRATION DATE | J.W. Krehbiel | | | | |
| 820246 8-13-10 | TELEPHONE NUMBER (417) 895-6868 | | | | |



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 08340 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1211 percent (w/vol) ethyl alcohol. The expiration date for this lot number is October 15, 2009 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL BAC DATAMASTER SERIAL NUMBER 204182 08/18/09

ARREST TIME: 14:00 SUBJECT NAME: TEST DOB: 12/12/89 SEX: M STATE/D.L.: MO/098 ARRESTING OFFICER: ΝĤ OFFICER I.D.: NA TESTING OFFICER: KREHBIEL/J/W OFFICER I.D.: 664 PERMIT NUMBER: 820246 EXPIRATION DATE: 08/13/10 MISCELLANEOUS DATA: POST UPGRADE

--- BREATH AMALYSIS ---

RADIO INTERFERENCE

Operator Signature__

Ru. Kil

2208-02

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

BAC DATAMANTER SERIAL NUMBER 204180 MISSOURI STATE HIGHWAY PATROL 28/10/29

EXPIRATION DATE: 08/13/10 PERMIT NUMBER: 000046 MISCELLANGOUS DATA: OFFICER I.D.: 664 TENTING OFFICER: KREHEIEL/J/U POST UPGRADE --- SUPERVISOR MODE ---

| ## पूर | 10 to 1 | #* () 당 | CC St St | (i) (i) (i) (i) | 14:41 803 | (f) (i) 可 T | हों (U |
|------------------------------------|---------------------|--------------------|----------------|--------------------------|--|------------------------|---|
| <u>5</u> 500. | VERIFIED | 00 00 | කු | (0) (5) (- | \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ | , 60, 60, 60, | <u>6</u> 000000000000000000000000000000000000 |
| BLANK TEST | INTERNAL NATARIBARD | EXTERMENT NATIONAL | WEARK HONA | EXTERMEL NIGHBD | BLANK TEST | EXTERNAL STANDARD | トのは 一文文は『英 |

OIM,

(1) H Z

Face This Side Down – This Edge In First

BAC DataMaster Evidence Ticket

BAC DATAMASTER SERIAL NUMBER 204182 MISSOURI STATE HIGHWAY PATROL 08/18/09 4...

--- DIAGNOSTIC CHECK ---

COMPUTER:

OKAY

PROGRAM (04-07-0000):

HEATERS

SAMPLE CHRABER:

980

OKA? FLOW DETECTOR:

HIGH SPEEDS

DETECTOR:

OKRY

OKRY FILTERS:

QUARTZ STANDARD:

CALIBRATION:

OKAY

HIJKLMNOPGRSTUVWXYZE∖]^_`abcdefghijklmno !"##X8'()*+,+,-,/8183456789:;/=>?@ABCDEFG PRINTER TENT L+<-->NUXBOUTBADD

Operator Signature_

2208-02

Operator Signature

State of Missouri DEPARTMENT OF HEALTH



PERMIT TYPE II



| JASON KREHBIEL | | | | |
|-----------------|--|--|--|--|
| is he calibr | reby authorized tage | instruct and supervise operators, train instructors, inspect pairs, and operate the following breath analyzer(s): | | |
| | | DATAMASTER | | |
| for the | e determination of sued under the pro | ne alcoholic content of blood from a sample of expired (alveolar) visions of sections 577.020 through 577.041, RSMo 1986. | | |
| Date | 08/13/08 | Tui C. Colant | | |
| | 820246 | Director of State Public Health Laboratory | | |
| Number | 08/13/2010 | | | |
| Expires | | | | |
| MO 580-07 | 771 (7-88) | - Director, Department of Health Leb. 4 (R7-88) | | |