

## MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY CMI INTOXILYZER 5000 MAINTENANCE REPORT

BREATH ALCOHOL PROGRAM

Complete this report in duplicate at the time of the regular monthly preventive maintenance check, and whenever instrument is repaired. Send copy to Department of Health; Retain original in department file.		
INTOXILYZER 5000 SN	DATE OF INSPECTION :	
66-004992	06-03-2009	
LOCATION OF INSTRUMENT (STREET AND CITY)	TIME OF INSPECTION	
Kansas City, MO (East Patrol Division)	0256 hours	
CHECKLIST	_ ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
Place a check (✓) to left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument.		
DVM TEST: (.350 +/150) 351 Passed		
DIAGNOSTIC CHECK (PRINTOUT ATTACHED)		
CHARACTER DISPLAY TEST Passed		
PRINT TEST (PRINTOUT ATTACHED) Passed		
TIME AND DATE Passed		
Run three tests using a standard solution. All three tests must be within +/- 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (USE CAL. CHECK MODE) (PRINTOUT ATTACHED)  0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE  0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)		
TEST 1 .  02 TEST 2 . /03	TEST 3	
SIMULATOR TEMPERATURE (34°+/2°C) 34.0 °C Passed		
DE PERFORM RFI TEST (PRINTOUT ATTACHED) Passed		
NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF SUBJECT BREATH TESTS IN EACH RANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS)		
REFUSALS 15 004 4 .0509 6 .1014 8	.1519 9 Over .19 5	
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).		
Tested and certified within Mo Dept. of Health guidelines		
Guth Laboratories, Lot 08400, 0.10 Solution, Exp. 12-08-09		
INSPECTING OFFICER		
SIGNATURE	PRINT NAME	
	Brad Lynn	
TYPE II PERMIT NUMBER/EXPIRATION DATE	TELEPHONE NUMBER	
720205 /10-01-09	816) 482-8142	

nico de la secola de la Electro de la Electro de la lacola Deservicio de la lacola

an 66-0099312 Ezas. 23 ESBN veb vak Vetak

ABCDEFGHIJKLINOFGRSTUUWXYZ8123 ABCDEFGHIJKLINOPGRSTUUWXYZ8123456789 ABCDEFGHIJKLINOFGRSTUWXYZ8123456789 GWYABCGE PYBEC DEFGHIJKLINOFGRSTUW ABCDEFGHIJKLINOFGRSTUW ABCDEFGHIJKLINOFGRSTUW

Sodi E zvim present Erv Influvit (ZER - Artoria AlviteZek No novel Sedo - Si 68 9842 86/82/2008

UTAGNOSTIL TEŠT

PROMILHEDA E235.23 PASSES
RAMICAECK PASSES
TEMP CHECK PASSES
PROCESSOR CHECK
EYMC PULSE PASSES
ASE STABILITY PASSES
REF RANGE PASSES

DIMENUSTIC

PASSI

PRINTAR CHECK PBCDEFGHITKLYWOFGRSTUUWXYZ G123456789 SS&L E 27TH STREET | EPD INTOXILIZER HEGUNOD ANNLYZER NO NODEL 5988 SH 66-884552 86/83/2889

TEST	Shine .	THE
AIR BLANK	. 666	63:63
CAL CHECK		14 7 8 5 6 6
AIR BLANK	. 888	193194
CAL. CHECK	. 193 *	- 633 84
AIR BLAKK	200	03:05
CAL. CHECK	.103	03:05
AIR BLAKK	. 200	45:46

NO RET PRESENT

SUBJECT NAME

LOCATION OF TEST

5301 E. 27th

OFFICER'S SIGNATURE & SERIAL NO.

Form 123 P.D. (8-91)

SUBJECT NAME

LOCATION OF TEST 5301 E. 2

275 K

Kcmo

OFFICER'S SIGNATURE & SEBIAL NO.

 $\mathcal{O}$ 

Form 123 P.D. (8-91)



## CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 08400 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1204 percent (w/vol) ethyl alcohol. The expiration date for this lot number is December 8, 2009 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

# State of Missouri DEPARTMENT OF HEALTH





# BRADLEY S. LYNN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

## INTOXILYZER 5000

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 10/01/07

Number **720205**Expires 10/01/2009

MO 580-0771 (7-88)

Director of State Public Health Laborator

Lab. 4 (R7-88)

Director, Department of Health