

MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY

BREATH ALCOHOL PROGRAM

CMI INTOXILYZER 5000 MAINTENANCE REPORT JUN -8 2009 Complete this report in duplicate at the time of the regular monthly preventive has because instrument to consider the Constant of House Potain original in department the is repaired. Send copy to Department of Health; Retain original in department file. INTOXILYZER 5000 SN LOCATION OF INSTRUMENT (STREET AND CITY) Warrensburg Police Dept. 102 S. Holden Warresnburg Mo. CHECKLIST Place a check (✓) to the left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument. DVM TEST: (.350 ± .150) _ 1 4 56 DIAGNOSTIC CHECK (PRINTOUT ATTACHED) WCHARACTER DISPLAY TEST GK PRINT TEST (PRINTOUT ATTACHED) THE AND DATE 6/03/2009 1703 0K CALIBRATION CHECK -Run three tests using a standard solution. All three tests must be within \pm 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (USE CAL. CHECK MODE) (PRINTOUT ATTACHED) 1 0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE ☐ 0.040% STANDARD — MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE. (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) TEST 2 SIMULATOR TEMPERATURE (34° ± .2°C) 34.0 C PERFORM RFI TEST (PRINTOUT ATTACHED) 🛛 NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF SUBJECT BREATH TESTS IN EACH BANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS) REFUSALS 0 - .04.05-.09 .10-.14 .15-.19 Over .19 List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary). Guth Labs .10 solution Lot No.08400 Exp. 12/G8/09 Instrument meets Department of Health Specifications.

INSPECTING OFFICER	
SIGNATURE	
	PRINT NAME
TYPE II PERMIT NUMBER/EXPIRATION DATE	Jeff Reynolds
17/90 250 /01/B/ac	TELEPHONE NUMBER
10 580-1355 (9-94)	660-747-9133

AN EQUAL OPPORTUNITY/AFFIRMATIVE ACTION EMPLOY



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 08400 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1204 percent (w/vol) ethyl alcohol. The expiration date for this lot number is December 8, 2009 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

William Charles THE WAT DEATH OF THE LATER PARTY TO THE LATER PARTY TO BE SOUTH TO THIS SIDE UP. THIS EDGE IN: FORM NUMBER 015010 THIS SIDE UP. THIS EDGE IN. FORM NUMBER-075070 金の大きには TIME FIRST OBSERVED のでは、 15 to 18 18 00 18 to 18 SCOFFICAL CLICATION TO ACCOMMENT OF THE CONTRACTOR SASCING ASCORDANCE OF THE CONTRACT THIS SIDE OF THIS EDGE IN FORM NOWBER 015010 ADDITIONAL INFORMATION AND/OR REMARKS Service of the servic を とのない を を のない を を のる

DEPARTMENT OF HEALTH State of Missouri

M/









IEFEREY REYNOLDS

calibrate, perform field repairs, and operate the following breath analyzer(s): is hereby authorized to instruct and supervise operators, train instructors, inspect,

INTOXILYZER 5000

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

12/18/07

Expires 12/1.8/2009

Number 720252

MO 580-0771 (7-88)

Director, Department of Health

Director of State Public Health Laboratory

Lab. 4 (R7-88)