



MISSOURI DEPARTMENT OF HEALTH
STATE PUBLIC HEALTH LABORATORY
DATAMASTER MAINTENANCE REPORT

DEATH ALCOHOL PROGRAM

Complete this report in duplicate at the time of the regular monthly preventive maintenance check, and whenever instrument is repaired. Send copy to Department of Health; retain original in department file.

DATAMASTER SN

BOLIVAR POLICE DEPARTMENT

LOCATION OF INSTRUMENT (STREET AND CITY)

345 S Main Bolivar, MO 65613

DATE OF INSPECTION

6/1/09

TIME OF INSPECTION

1531 HOURS

CHECKLIST: Place a check (✓) to the left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument.

DIAGNOSTIC CHECK (PRINTOUT ATTACHED)

COMPUTER

DETECTOR

PROGRAM

FILTERS

HEATERS SAMPLE CHAMBER *49* °C

QUARTZ STANDARD

FLOW DETECTOR

CALIBRATION

PUMP HIGH SPEED

PRINTER

INDICATOR LIGHTS

TIME AND DATE

SIMULATOR TEMPERATURE (34 °C ± 0.2 °C) *34.0 °C*

CALIBRATION CHECK

Run three tests using a standard solution. All three tests must be within \pm 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) (USE RECIRCULATION PUMP)

0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE

0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

(ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

TEST 1 *.100*

TEST 2 *.099*

TEST 3 *.099*

PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF BREATH TESTS IN EACH RANGE AS FOLLOWS. (DO NOT INCLUDE SIMULATOR TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	1	(.10-.14)	1	(.15-.19)	0	(Over .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary)

PASSED DEPARTMENTS OF HEALTH STANDARDS

GUTH LABS .10 LOT # 08340 EXPIRES: OCTOBER 15, 2009

INSPECTING OFFICER

SIGNATURE

Brian Laynard

TYPE/PHONE NUMBER/EXPIRATION DATE

820190

06/09/2010

PRINT NAME

BRIAN LAYNARD

TELEPHONE NUMBER

417-326-5297



GUTH LABORATORIES, INC.

590 NORTH 67TH STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-584-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number **08340** of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography and found to contain **0.1211** percent
(w/vol) ethyl alcohol. The expiration date for this lot
number is **October 15, 2009** at **11:59 PM**.

When used in a calibrated Simulator, operating at
 $34^{\circ}\text{C} \pm .2^{\circ}\text{C}$, this solution will give a breath alcohol
analysis instrument reading of **0.10** percent BAC.

The alcohol and water used in this solution were
free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
BOLIVAR POLICE DEPARTMENT

BBC INSTRUMENT SERIAL NUMBER 958818
06/01/89

ARREST TIME: 16:25
SUBJECT NAME: DELLON

DOB: 07/27/77 SEX: M
STATE/I.D.#: NY/NA
ARRESTING OFFICER:
NO

**OFFICER-IN-CHARGE
TESTING OFFICERS
PUNjab Province**

CHILLON, L. S. 15
PENNSYLVANIA RAILROAD 888192

MISCELLANEOUS DATA
RE-A CHECK

卷之三

BLACK TEST
 INTERNAL STANDARD
 PERIODIC INTEGRITY
 VERIFIED
 16:48
 16:48

STATE OF MISSOURI
KANSAS CITY POLICE DEPARTMENT

BIG INTEREST SERIAL NUMBER 9500100

TESTING OFFICER:
RICHARD BRITTON
OFFICER I.D.: 15
PERMIT NUMBER: 828199
EXPIRATION DATE: 05/09/10
MISCELLANEOUS DATA:

卷之三

	VERIFIED	TEST
INTERNAL STANDARD	100	100
EXTERNAL STANDARD	100	100
BLANK TEST	0.00	0.00
INTERNAL STANDARD	100	100
BLANK TEST	0.00	0.00
EXTERNAL STANDARD	100	100
BLANK TEST	0.00	0.00

卷之三

OPERATOR SIGNATURE

OPERATOR SIGNATURE

Card Stock
Glossier

No.

**REORDER ALL SUPPLIES FROM N.P.A.S.S.
P.O. BOX 1435, MANSFIELD, OH 44901**

REORDER ALL SUPPLIES FROM N.P.A.

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
T Y P E II



BRIAN RAYNARD

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 06/09/08

Toni C. Polk

Director of State Public Health Laboratory

Number 820190

Director, Department of Health

Lab. 4 (R7-88)

Expires 06/09/2010

MO 580-0771 (7-88)

BAC DataMaster
Evidence Ticket

STATE OF MISSOURI
BOLIVIAN POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 9500018
06/01/09
15:31

--- DIAGNOSTIC CHECK ---

COMPUTER: OKAY

PROGRAM: OKAY

HERTERS
SAMPLE CHAMBER: 49C

FLOW DETECTOR: OKAY

PUMP
HIGH SPEED: OKAY

DETECTOR: OKAY

FILTERS: OKAY

QUARTZ STABILIZER: OKAY

CALIBRATION: OKAY

PRINTER TEST
! "555" ()**+-./3123456789;:;<=>?#ABCDEF
HIJKLMNOPQRSTUVWXYZ\^_`abcdafghijklmn
pqrsuvwxyz{}!}{+}

OPERATOR SIGNATURE

B. Raynard

Card Stock No.

REORDER ALL SUPPLIES FROM N.P.A.S.
P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST