

MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY

BREATH ALCOHOL PROCEAM

DATAMASTER MAINTENANCE REPORT

estate .					11.11.1	0.000	
Complete this report in duplicate at the time is repaired. Send copy to Department of Health	of the regular retain original	monthly prever	ntive maint ile.	lenance c	heck, and	Twhenever ins	trument
DATAMASTER SN 950071	·		NYTA-CONSTRUCTION CLASS CONTRACT AND CLASS CONTRACT AND CLASS CONTRACT AND CLASS CONTRACT AND CLASS CONTRACT CO	Shi	DATE OF 18 05/30/2	適性のプロリー 009	
LOCATION OF INSTRUMENT (STREET AND CITY) 415 Elm Grove Lane Hazelwood, MO 63042				ريقيع بين الأدار ال	TIME OF IN 03:28		
CHECKLIST: Place a check (/) to the left of e in observed values where determined.) Uncheck	each item if fou					tablished limits	s. (Write
D DIAGNOSTIC CHECK (PRINTOUT ATTAC	CHED)						
☑ COMPUTER		DETECT	☑ DETECTOR				
☑ PROGRAM		☑ FILTERS	☑ FILTERS				
☑ HEATERS SAMPLE CHAMBER °C		☑ QUARTZ STANDARD					
☑ FLOW DETECTOR		☑ CALIBRA	☑ CALIBRATION				
☑ PUMP HIGH SPEED		2 PRINTER	PRINTER				
☑ INDICATOR LIGHTS							
☑ TIME AND DATE							
SIMULATOR TEMPERATURE (34 °C ± 0.2°C) 34.0 degrees C							
☑ CALIBRATION CHECK -							
Run three tests using a standard solution. All three tests must be within \pm 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) (USE							
RECIRCULATION PUMP)	responding to	ine siandaro so	aution beir	ig usea. (i	PHINIOC	JI ATTACHED) (USE
☑ 0.100% STANDARD - MUST READ BET	WEEN 0.095%	and 0.105% INC	LUSIVE				
O.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)							
TEST 1 .099 TE	ST2	.098		TEST 3	F	.098	
PERFORM R.F.I. TEST (PRINTOUT ATTAC	CHED)						
☑ NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF BREATH TESTS IN EACH RANGE AS							
FOLLOWS: (DO NOT INCLUDE SIMULA		1				ı	
REFUSALS () (004) () (.050		(.1014)		1519)	0	(Over .19)	1
List any new parts and describe any alteration and within established limits (use other side if n		n that was mad	e to restor	e the insti	rument to	operate satisf	actorily
The instrument was operating within DOHSS specifications. No alterations or modifications were made. "Guth							
Laboratories Inc." ethanol solution creating a .10 vapor, was used; lot number 08280, bottle number 1196, expiring							
08-11-2009.	The second secon	OFFICE OF THE STATE OF THE STAT		artinud 100,0 million og 100,0 dega helyndren legen, og 100,0 million og 100,0 million og 100,0 million og 100			

INSPECTING OFFICER							
SIGNATURES SIGNATURES	37V	PRINT NAME Anthony T	Kristo DS	N #378			
TYPE II PERMIT NUMBER/EXPIRATION DATE		Anthony T. Kristo DSN #378					
720224 - 11/13/2009)	(314) 513-5220				



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 08280 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1212 percent (w/vol) ethyl alcohol. The expiration date for this lot number is August 11, 2009 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

Face This Side Down – This Edge In First

BAC DataMaster Evidence Ticket

HAZELWOOD POLICE DEPT.

BAC DATAMASTER SERIAL NUMBER 950071 05/30/09 03:28

___ DIAGNOSTIC CHECK ---

COMPUTERS

OKAY

PROGRAM:

OKAY

HEATERS ____

49c

SAMPLE CHAMBER:

T-1"

FLOW DETECTOR:

OKAY

PUMP

HIGH SPEED:

OKAY

DETECTOR:

OKAY

FILTERSE

OKAY

QUARTZ STANDARD:

OKAY

CALIBRATION:

OKAY

PRINTER TEST

###%&'()*+*-./0123456789::<=>?@ABCDEFG
HTUKLMMOPGRSTUVWXYZ[\]^_'abcdefahijklmno
###*stuvwxaz{|}**

With agn-based into

CMSU 2

Face This Side Down - This Edge In First

BAC DataMasterEvidence Ticket

HAZELWOOD POLICE DEPT.

BAC DATAMASTER SERIAL NUMBER 950071 05/30/09

TESTING OFFICER:
KRISTO/TONY
OFFICER I.D.: 0378
PERMIT NUMBER: 720224
EXPIRATION DATE: 11/13/09
MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLAMK TEST	" 666	03:48
INTERNAL STANDARD	VERIFIED	03:48
EXTERNAL STANDARD	. 099	03:48
RI ANK TEST	. DDG	03:49
EXTERMAL STAMDARD	. 998	03:49
BLANK TEST	. 999	03:50
FXTERMAL STAMDARD	. 098	03:50
BLANK TEST	<u>. 808</u>	Ø3:51

| N = 3 | SIM. = .1 | AVG. = .0983

Printed on recycled paper with agri-based inks

Operator Signature 10/43/3 373

CMSU 2208-02

Face This Side Down - This Edge In First

BAC DataMasterEvidence Ticket

HAZELWOOD POLICE DEPT.

BAC DATAMASTER SERIAL NUMBER 950071 05/30/09

ARREST TIME: 20:00 SUBJECT NAME: RF1/TEST DOB: 89/89/80 SEX: M STATE/D.L.: MO/ ARRESTING OFFICER: KRISTO/TOMY OFFICER I.D.: 0378 TESTING OFFICERS KRISTO/TOMY OFFICER I.D.: 0378 PERMIT NUMBER: 720224 EXPIRATION DATE: 11/13/09 MISCELLAMEOUS DATAS RFI TEST

--- BREATH ANALYSIS ---

BLANK TEST INTERNAL STANDARD RADIO INTERFERENCE .000 VERIFIED 03:53 03:53

Operator Signature

Printed on recycled paper with agri-based inks

CMSU 2208-02

State of Missouri DEPARTMENT OF HEALTH





ANTHONY KRISTO

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 11/13/07

Director of State Public Health Laboratory

Number 720224

Expires 11/13/2009

Director, Department of Health

Lab. 4 (R7-88)

MO 580-0771 (7-88)

(7-88)