

MISSOURI DEPARTMENT OF HEALTH STATE PUBLIC HEALTH LABORATORY CMI INTOXILYZER 5000 MAINTENANCE REPORT

RECEIVED DHSS Breath Alcohol Program By Carol Day at 8:14 am, Mar 12, 2010

Complete this report in duplicate at the time of the regular monthly preventive maintenance check, and whenever instrument is repaired. Send copy to Department of Health; Retain original in department file.			
INTOXILYZER 5000 SN	DATE OF INSPECTION		
66-005179	03-01-2010		
LOCATION OF INSTRUMENT (STREET AND CITY)	TIME OF INSPECTION		
10000 E 59 th Street Raytown, MO 64133	0915 Hrs.		
CHECKLIST 10913 11/8.			
Place a check (\checkmark) to left of each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unchecked items must be corrected before using instrument.			
☐ DIAGNOSTIC CHECK (PRINTOUT ATTACHED) OK			
☐ CHARACTER DISPLAY TEST OK			
☑ PRINT TEST (PRINTOUT ATTACHED) OK			
☐ TIME AND DATE 09 Hr 20 Min 03-01-2010			
 CALIBRATION CHECK- PASSED Run three tests using a standard solution. All three tests must be within +/- 5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (USE CAL. CHECK MODE) (PRINTOUT ATTACHED) ☑ 0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE ☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) 			
TEST 1 .097 % TEST 2 .096 %	TEST 3 .096 %		
SIMULATOR TEMPERATURE (34° +/2°C) 34.0 Degrees Centigrade			
PERFORM RFI TEST (PRINTOUT ATTACHED) OK			
NUMBER OF REFUSALS, SINCE LAST MAINTENANCE REPORT, AND NUMBER OF SUBJECT BREATH TESTS IN EACH RANGE AS FOLLOWS: (DO NOT INCLUDE SIMULATOR TESTS)			
REFUSALS 0 004 1 .0509 0 .1014 1	.1519 2 Over .19 1		
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).			
The monthly maintenance tests were performed on the instrument as per the Missouri Department of Health			
regulations and the instrument was found to be operating within established limits.			
Manufacturer: Guth Laboratories, Inc. Concentration: .10% Expires: March 01, 2010 at 11:59 PM Lot: 09270			
INSPECTING OFFICER			
SIGNATURE SIM SKY STEERS	PRINT NAME		
TYPE H DEDAUTH WARDEN TO THE TOTAL T	Corporal Jeffrey S. Keith		
TYPE II PERMIT NUMBER/EXPIRATION DATE	TELEPHONE NUMBER		
200013 03-01-2010	816-737-6020		



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 09270 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography and found to contain 0.1207 percent (w/vol) ethyl alcohol. The expiration date for this lot number is September 23, 2010 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.10 percent BAC.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

10000 E 59 ST RAYTOWN MO 64133 INTOXILYZER - ALCOHOL ANALYZER MC MODEL 5000 SN 66-005179 03/01/2010

DIAGNOSTIC TEST

09:30

BROW CHECK TENY CHECK TENY CHECK £735, 23 PASSED PASSED PASSED PROCESSOR CHECK SYNC PULSE SYNC SPEED PASSED PASSED NEG STABILITY POS STABILITY PASSED PASSED. REF RANGE PASSED PASSED DIAGNOSTIC

PRINTER CHECK ABCDEFGHIJKLMNOPORSTUUWXYZ 0123456789

THIS SIDE UP. THIS EDGE IN. FORM NUMBER 015010

16000 E 59 ST RAYTOWN MO 64133 INTOXILYZER - ALCOHOL AMALYZER MO MODEL 5000 SN 66-005129 SN 65-005179 03/01/2010

TEST	XBAC	TATE
AIR BLANK	, 000	
CAL. CHECK	. 097	99:33
AIR BLANK	.000	99433
CAL, CHECK	.098	99:33
AIR BLANK	. 000	09:34
CAL. CHECK	, 096	99:34
AIR BLANK	. 000	89:35

NO REI PRESENT

SUBJECT'S NAME

TIME FIRST OBSERVED

INSTRUMENT LOCATION

ADDITIONAL INFORMATION AND/OR REMARKS

SN 66-895179 E735, 23

93/91/2010 Ø9:31

ABCDEFGHIJKI MNOPORSTUVWKYZ0123 MELLER BITLURL PINDPURS LUUMET 20123
ABCDEFGHIJKLINDFORSTUUMEY 20123456789
ABCDEFGHIJKLINDFORSTUMEY 2012345678919458bcde
FTEXCELER GIFFET LIFEL PIFFUR
FRECDEFGHIJKLING SRSYUM
ABCDEFGHIJKLING SRSYUM
ABCDEFGHIJKLING SRSYUM ABCDEFCHIOKUMMOPORSTUUMXYZ012345678910#4sbcde

THIS SIDE UP. THIS EDGE IN. FORM NUMBER 015010

SN 66-0051.79 E735, 23 INVALID TEST IMHIBITED - REI 03/01/2010 09:37

SUBJECT'S NAME

TIME PAST OBSERVED

INTOXILYZER® INSTRUMENT PRINTER CARD

ODITIONAL INFORMATION AND/OR REMARKS

State of Missouri DEPARTMENT OF HEALTH



MO 580-0771 (7-88)

TYPE



JEFFREY S KEITH

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

INTOXILYZER 5000 for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041. RSMo 1986. 01/12/2010 Interim Director Date Director of State Public Health Laboratory 200013 01/12/2012 Director, Department of Health Lab. 4 (R7-88)